

CHAPTER 925 - Surface Water Discharge^[11]

Sections:

Footnotes:

--- (11) ---

Cross reference— Obstructing drainage - see S. & P. S. Ch. 911

925.01 - DOWNSPOUT AND GUTTER DRAIN CONNECTIONS PROHIBITED.

The connection of roof downspout and gutter drains, either directly or indirectly, into the sanitary sewerage system shall not be permitted under any circumstances. Any such connections found shall be immediately disconnected and their use immediately discontinued.

(Ord. 53-61. Passed 12-4-61.)

925.02 - FOUNDATION DRAIN CONNECTIONS PROHIBITED.

The connection of foundation drains in any way or manner, direct or indirect, into the sanitary sewerage system shall not be permitted under any circumstances. All such drains found to be so connected shall be immediately disconnected and such use discontinued.

(Ord. 53-61. Passed 12-4-61.)

925.03 - GROUND WATER DRAINAGE; SUMP PUMP.

Where a pipe or closed conduit is installed around the foundation of a building or structure for the purpose of draining ground water away from the foundation, a sump pump shall be used to dispose of such ground water by pumping it into a downspout drain to the curb, a storm sewer or other adequate outlet exterior to the house, other than any appurtenance of the sanitary sewerage system.

(Ord. 53-61. Passed 12-4-61.)

925.04 - CONDUIT CONNECTIONS FOR SURFACE, ROOF WATER PROHIBITED.

No person shall connect or cause to be connected to the sanitary sewerage system of the City or any part thereof, any conduit which conveys directly or indirectly surface or roof water from any building, structure, yard or paved surface.

(Ord. 53-61. Passed 12-4-61; Ord. No. [0032-2016](#), § 1(Exh. A), 4-18-16)

925.99 - PENALTY.

Any officer of any corporation or any person who violates the provisions of this chapter or installs storm drains, foundation drains or roof drains contrary to the provisions of this chapter shall be fined not more than \$50.00 per day, per violation.

(Ord. 53-61. Passed 12-4-61.)